



16" OR 24" ON-CENTER APPLICATIONS

Installation Instructions

FRPS Corp Enclosure # FN-Z-12-20-9

1. Position product against floor/ceiling joists, turning enclosure so it fits into floor/ceiling cavity, depending on 16" or 24" joist spacing.
2. Using pilot holes in flanges, attach enclosure to joists with a minimum of four (4) #6 x 1-1/4" drywall screws or equivalent.
3. Apply intumescent fire sealant (**3M™ Fire Barrier CP 25WB+ Sealant** or comparable product) to fill voids and cavities around the power supply wire access holes.

Should you have any questions, contact our technical support team at 612.294.1450 or info@FRPSonline.com.